


# BERNHARDT | design

## Alta

Cory Grosser



# BERNHARDT | design

## Alta

Cory Grosser



### Mid Back

Fixed or Adjustable Height

Upholstered Arm Pads

W27" D27" H33<sup>3</sup>/<sub>4</sub> – 36<sup>3</sup>/<sub>4</sub>"

Seat Height: 17<sup>1</sup>/<sub>2</sub> – 20<sup>1</sup>/<sub>2</sub>"

Arm Height: 24 – 27"



### Mid Back, Upholstered Pad

Fixed or Adjustable Height

Upholstered Arm and Back Pads

W27" D27" H33<sup>3</sup>/<sub>4</sub> – 36<sup>3</sup>/<sub>4</sub>"

Seat Height: 17<sup>1</sup>/<sub>2</sub> – 20<sup>1</sup>/<sub>2</sub>"

Arm Height: 24 – 27"



### High Back

Fixed or Adjustable Height

Upholstered Arm Pads

W27" D27" H36<sup>3</sup>/<sub>8</sub> – 39<sup>3</sup>/<sub>8</sub>"

Seat Height: 17<sup>1</sup>/<sub>2</sub> – 20<sup>1</sup>/<sub>2</sub>"

Arm Height: 24 – 27"



### High Back, Upholstered Pad

Fixed or Adjustable Height

Upholstered Arm and Back Pads

W27" D27" H36<sup>3</sup>/<sub>8</sub> – 39<sup>3</sup>/<sub>8</sub>"

Seat Height: 17<sup>1</sup>/<sub>2</sub> – 20<sup>1</sup>/<sub>2</sub>"

Arm Height: 24 – 27"